

The drawing shows the front panel of the Mikont-186 universal controller. It is a rectangular device with rounded corners and four mounting holes at the corners. The top section is labeled 'A1' and contains the following text: 'Миконт-186', 'Серия МС-701', and 'Универсальный контроллер'. To the right of this text is a large rectangular display area. Below the display is a keypad with nine buttons arranged in two rows: the top row has 'ESC', 'F1', an up arrow, 'F2', and a 'SET' button; the bottom row has an asterisk (*), a left arrow, a down arrow, a right arrow, and another 'SET' button. The bottom section is labeled 'A2' and shows three terminal blocks on the left and three on the right, each labeled 'PG 11'.

A1

Миконт-186

Серия МС-701

Универсальный контроллер

ИВС-МИКОНТ Пермь, Россия
Научно-производственное предприятие

ESC F1 ↑ F2 SET

* ← ↓ → SET

A2

PG 11 PG 11 PG 11

PG 11 PG 11 PG 11

Инв. № подл.	Подп. и дата	Взам. инв. №